



## Assembly Line Automatic Labeling Machine HL-T-900



Online labeling applicator, can be related to the production line, the flow of products, on the plane, curved labeling, implementing online marking, realize supporting to spurt the code conveyor belt, the flow through the object labeling

### Technical Parameter:

Model	HL-T-900	
Labeling Accuracy	±1mm	
Labeling Speed	30-100pcs/min	
Applicable Dimensions	Depends on the pipeline delivery parameters	
Applicable Labe Size	Length	6mm-200mm
	Width	6mm-180mm
Power Supply	220V/50HZ	
Weight	70KG	
Machine Size(LxWxH)	About 1100mm*700mm*1450mm	
Delivery Time	20-25Days	
Type	Manufacture, Factory,Supplier	
Packaging	Wooden box	
Shipping Method	Sea,Air and Express	
Payment Term	L/C,T/T,Money Graml etc	

## Machine Adjustment

1. Label overlay device: adjusts the foam (rubber) roller and make it parallel to the product and make sure its pressure to each part of the products are equal, meanwhile ensure that the roller can fully cover and touch the label, and ensure the stability of the labeling position.
2. Label peeling plate: loosen the “L” bar on the support part of label peeling plate, then can adjust the peeling plate in a certain angle to meet different products labeling needs. For different thickness and materials labels, the label peeling plate angle might need to be adjusted so as to peel the labels smoothly.
3. Electric Eye (sensor) Adjustment: The machine is equipped with 2 sets of electric eyes, which are respectively named as object detecting electric eye and label detecting electric eye. They need to be adjusted according to the actual need in product.
  - 1) Sensor setting: The standard sensor for this machine is Mitac type electric eye. Other options for labeling detecting sensor and object detecting sensor are available.
  - 2) Put the labeled place in the U socket of the electric eye and press and hold the adjustment button for about 3 seconds until the electric sensor’s yellow light blinking and then release the button. Put the no-label gap (only backing paper) into the U-groove and hold the adjusting button for 8 seconds then release the button. At this time, the setting is completed.