

GTB-200 Type High Speed Non-drying-glue Sticking Mark Machine



Description: This machine is used to stick mark circumferentially to column-model vessel, it is a mating product of ZP- II type omni-auto-counting and bottling line of pill, tablet, soft and hard capsule of our company, it can be used stand-alone and also can be used other matching product line.

Working principle

Un-drying-glue labeling tray strap made in advance put in the back of the machine, tags will be peeled off automatically through photoelectrical sensor and serving generator system, and stick on the outside surface of column-model vessel, and thus, it finishes sticking mark process.

Technical characteristics

1. Accurate position of sticking mark, reliable, it can realize sticking mark half- circumferentially or whole-circumferentially.
2. Full function of printing data, clear writing, and position adjustable.
3. It can add up and display team output and gross per batch.
4. Simple regulation, wide adaptive range.

Technical parameters

1. Output: 100-200 bottle per minute
2. Qualification of bottle: $\phi 20$ - $\phi 100$ mm (diameter)
3. Mode of sticking mark: half-circumference and whole-circumference
4. Character of sticking mark: opacity and translucence
5. Total power: 1kw
6. Power source: three-phases AC 380V
7. Air pressure: 0.4MPa consuming gas tolerance: 0.05m³/min
8. Weight of whole machine: 150kg